

Introduction

The new Livingston Enterprises ComOS™ 3.5 software release is now available for the PortMaster™ 3 Integrated Access Server. This release is provided at no charge to all Livingston customers.

This release note documents commands and features in ComOS release 3.5 in addition to those described in the OSPF chapter of the *Command Line Administrator's Guide* (available in late December, 1996) and the "Configuring the PortMaster 3" chapter of the *PortMaster 3 Installation Guide* (included with the PortMaster 3). Both manuals are available in PostScript and Adobe Acrobat PDF format on the Livingston Enterprises FTP site, <ftp://ftp.livingston.com:/pub/le/doc/manuals/>.

Contents

Introduction	1
Contents	1
New Features in ComOS 3.5	1
Digital Modem Specifications	2
Modem Support	2
T1/E1 Loopback	3
Variable Length Subnet Masks	3
Assigned Pool Size	4
OSPF	4
Modem Commands	5
MultiChassis PPP	7
Quick Setup Example	8
Copyright and Trademarks	9
Notices	9
Contacting Livingston Technical Support	9

New Features in ComOS 3.5

ComOS 3.5 includes the following new features:

- Support for the PortMaster 3 Integrated Access Server and True Digital Modems.
- Variable Length Subnet Masks. In previous releases ComOS required the same netmask to be used for all subnets of a network. In release 3.5 variable length subnet masks (VLSM) are supported. To ease the transition, the command "set user-netmask off" is available; see below for details.

-
- OSPF - see the OSPF Chapter in the Command Line Administrator's Guide, which is available now in PostScript and Adobe Acrobat PDF format on our FTP site <ftp://ftp.livingston.com/pub/le/doc/manuals/> and will be available in printed form in late December, 1996.
 - Multichassis PPP. The "set endpoint" command now enables MultiChassis PPP.
 - The size of Assigned Address Pool can be set with the "set pool" command.

Digital Modem Specifications

Data Modulations:

- ITU V.34 - 28,000 bps et al.
- ITU V.8 - V.34 capabilities negotiations
- ITU V.32bis - 14,400, 12,000, 9600, and 7200 bps with trellis encoding
- ITU V.32 - 9600 and 4800 bps
- ITU V.22bis - 2400 bps
- Modulation supervision for automatic rate selection and bit error performance monitoring for automatic fallback and fallforward.

Support for ITU V.34 Annex 12 - 33,600 bps will be added in a future release.

High Level Data Protocols:

- V.42 (includes LAPM and MNP 2-4 error correction protocols)
- V.42bis data compression algorithm
- MNP 5 data compression algorithm

Modem Support

Following is a list of Modems tested for compatibility with the True Digital™ Modems in the PortMaster 3. For a more complete list see

<http://www.livingston.com/Products/pm3qa.shtml> and

<http://www.livingston.com/Tech/Appnotes/index.shtml>.

- All USR V.32, V.32bis & V.34 modems should connect with no problem.
- USR Courier V.32, V.32bis, V.34 Dual Standard Fax modems. Stand-alone & PCMCIA CONNECT 28800/ARQ/V34/LAPM/V42BIS
- USR Sportsters, Options V32bis,V.34 Stand-alone & PCMCIA CONNECT 28800/ARQ/V34/LAPM/V42BIS
- TDK V.fast PCMCIA CONNECT 14400/REL - LAPM Note: V.fast is not supported, so this modem will only connect at 14.4k Practical Peripherals PM14400FXMT 14400, LAP-M, V.42bis 512/6 Connections
- Cardinal 33.6 V.34/V.FC CONNECT 115200/v34/lapm/v42bis/28800:TX/28800:RX
- Hayes Accura 288 v.34+fax CONNECT 115200/lapm
- Boca v.34/data+fax CONNECT 115200/v34/lapm/v42bis/28800:TX/28800:RX
- Zoom Fax modem v.34x plus CONNECT 115200/v34/lapm/v42bis/28800:TX/28800:RX
- Supra Express 33.6

T1/E1 Loopback

set *Line0* loopback on | off

When line0 or line1 is set to T1 or E1 operation, you can set it for local network loopback, for testing purposes.

Variable Length Subnet Masks

ComOS release 3.5 now supports Variable Length Subnet Masks. In previous releases ComOS required the same netmask to be used for all subnets of a network. In release 3.5 variable length subnet masks (VLSM) are supported. To ease the transition, the command “set user-netmask off” will treat all netmasks specified in the User Table or RADIUS as though they were 255.255.255.255, the way earlier releases did. The command “set user-netmask on” will add a route based on the specified netmask. The default is off.

In ComOS release 3.3.3 and earlier the PortMaster always used 255.255.255.255 for the user’s Framed-IP-Netmask, regardless of the value of the Attribute. ComOS 3.5 adds support for Variable Length Subnet Masks (VLSM) but by default ignores the Framed-IP-Netmask the same way earlier releases did. To have 3.5 accept the netmask value, issue the following commands on the PortMaster:

```
set user-netmask on
save all
```

After user-netmask is set on, the PortMaster will use the actual value of the Framed-IP-Netmask to update the routing table when a user logs in. USE CAUTION with this feature, since it affects both routing and Proxy ARP on the PortMaster.

If you only want to route to that one host, use the attribute

```
Framed-IP-Netmask = 255.255.255.255
```

You should always use Netmask 255.255.255.255 when using the PortMaster assigned address pool (or omit the attribute, which defaults to 255.255.255.255).

If you want to route to an entire 24-bit subnet, you would use

```
Framed-IP-Netmask = 255.255.255.0
```

Note that in some cases this may mean that the Framed-Route attribute may no longer be necessary.

Assigned Pool Size

The PortMaster allocates a pool of IP addresses starting at the Assigned Address (set from the global menu or by the “set assigned”) and counting up. The total number of addresses is equal to the number of ports configured for Network Dialin. If someone dials in and requests an unused address from the pool, that is assigned; if someone dials in and requests any address, the next address from the pool is assigned, if someone disconnects, their address is placed at the end of the pool for re-use. In Release 3.5 the size of the pool can also be set explicitly with the “set pool Number” command, where Number will be the number of IP addresses allocated to the pool. If the pool size is decreased the PortMaster should be rebooted for the change to take effect.

OSPF

See the OSPF Chapter in the *Command Line Administrator's Guide*, which is available now in PostScript and Adobe Acrobat PDF format on our FTP site <ftp://ftp.livingston.com/pub/le/doc/manuals/> and will be available in printed form in late December, 1996. Some additional commands were added after that manual went to press and are documented here.

Before configuring ospf, you must first do the following:

```
set ospf enable
save all
reboot
```

reset ospf

The “reset ospf” command resets the OSPF router engine in the PortMaster, and should be used after making changes to the PortMaster’s OSPF configuration.

OSPF cost, hello-timer, dead-timer

OSPF cost, hello-timer and dead-timer are now configurable by interface. Note: The value for cost, hello-interval and dead-time must be the same for all routers attached to a common network.

set Ether0 ospf on cost Number

This command determines the cost of sending a packet on the interface, expressed in the link state metric. Number is a number from 1 to 65535. The default value is 1.

Example: set ether0 ospf on cost 2

set Ether0 ospf on hello-interval Number

This command determines how often the hello packet is transmitted, from 10 to 120 seconds. The default value of hello-interval is 10 seconds.

Example: set ether0 ospf on hello-interval 40

set Ether0 ospf on dead-time Number

This is the number of seconds after ceasing to hear a neighbor router's hello packets, that the remote router is marked as down. Range is 40 to 1200 seconds. The default value is 40 seconds.

Example: set ether0 ospf on dead-time 60

Modem Commands

The following commands were added after the *Command Line Administrator's Guide* went to press.

```
set location Locname analog on | off
show modems
show M0
set debug mdp-events | mdp-status | mdp-internal | mdp-max on | off
set location Locname analog on | off
```

on = use an analog modem to dial out to this location

off = use isdn to dial out to this location

Dialout locations can use either analog modem or ISDN. It uses PAP or CHAP to authenticate itself to the location dialed. The remote end must auto-detect PPP; you cannot use dialout chat scripts in ComOS release 3.5 on the PortMaster 3.

Show modem displays the modem status; ACTIVE if the modem is in use, READY if the modem is available for use, ADMIN if the modem has been busied out.

```
pm3> show modem
```

Mdm	Port	Status	Speed	Compression	Protocol	Calls	Retrain	Disconnect
---	----	-----	-----	-----	-----	-----	-----	-----
M0	S2	ACTIVE	28800	V42BIS	LAPM	2	0	NORMAL
M1	S3	ACTIVE	28800	V42BIS	LAPM	1	0	NORMAL
M2	S4	ACTIVE	28800	V42BIS	LAPM	1	0	NORMAL
M3		READY	UNKNWN	NONE	NONE	0	0	NORMAL

```

pm3> show m0
      State:    ACTIVE
      Active Port: S2
      Transmit Rate: 28800
      Receive Rate: 28800
      Connection Type: LAPM/V42BIS
      Chars Sent: 8537870
      Chars Received: 7563501
      Retrans: 0
      Renegotiations: 0

      Total Calls: 3
      Modem Detects: 3
      Good Connects: 3

      Connection Failures
      No Modulation: 0
      No Protocol: 0
      Not Operational: 0
      Total Failed: 0

      Session Terminations
      Lost Carrier: 0
      Normal Disconnect: 2

```

The Mdm column in “show all” indicates which modem the port is using, if it is using a modem.

```

pm3> show all

```

Port	Speed	Mdm	Host	Type	Status	Input	Output	Pend
----	-----	---	-----	-----	-----	-----	-----	----
C0	9600	off	server	Login	USERNAME	0	30	0
S0	28800	M2	server	Login	/ COMMAND	1126499	4341532	0
S1	28800	M1		Device	ESTABLISHED	912355	3707007	0
S2	64000	on	ptp49	Netwrk	ESTABLISHED	783691	874518	0
S3	64000	on	server	Netwrk	CONNECTING	63057187	64106116	0
S4	64000	on	server	Login	/ IDLE	99463	789349	0

Debugging Modems

```
set debug mdp-events | mdp-status | mdp-internal | mdp-max on | off
```

Use these commands to turn on and off modem debugging to the console.

MultiChassis PPP

MultiChassis PPP (MCPPP) supports Multilink PPP (RFC 1717) across multiple PortMasters sharing an ethernet, to allow the use of MP across multiple PortMasters in a single telephone hunt group. To enable MCPPP use the “set endpoint” command.

MCPPP Features

Load balancing - In a hunt group configuration, traffic will be automatically switched to subsequent units if it is saturated on the first unit.

Master and Slave Links - If the Master link goes down for any reasons, the Master unit will continue process the Slave links as long as they still exist.

Master and Slave units - If the Slave unit is out of service, the Master links will continue to function. However, if the Master unit is out of service, the Slave links will cease to exist since the Master unit is required to process its links. MCPPP Commands

Enabling MCPPP

Use the following commands on all PortMasters sharing a hunt group and Ethernet, using the same 12 digit hexadecimal endpoint discriminator on all of them. For convenience you may wish to use one PortMaster’s ethernet MAC level address as the endpoint discriminator for all the PortMasters on that hunt group, but any 12-digit hexadecimal number will work.

```
set endpoint 00C005123456
save all reboot
```

The Endpoint Discriminator takes effect after the PortMaster is rebooted.

show mcppp

This command displays the mcppp table with the neighboring units in the same domain, the port number, user name, destination, the port type, and the IP addresses of the peer units.

show global

This command displays the End Point Discriminator address.

show session

The “show session” command on the Master unit now shows the virtual ports that are corresponding to the physical ports of the Slave unit. The virtual ports indicate by the letter V followed by the port number.

reset V0

V0 is a virtual port number, v0, v1, etc. This command is used on the Master unit to reset the virtual port. Since the virtual port has a corresponding physical port on the Slave unit, once the virtual port is reset on the Master, its corresponding physical port will not be available on the Slave.

Debugging MCPPP

To enable MCPPP debugging, use the “set console” command followed by any of the following commands:

set debug mcppp-event

Displays all the events related to the MCPPP links

set debug mcppp-history

Displays the most recent 40 events

To disable debugging, use the “set debug off” command, and “reset console” to release the console.

Quick Setup Example

This example configures a PortMaster 3 to use two PRI lines for dial-in by modem or ISDN users, with RADIUS authentication and accounting. Refer to the “Configuring the PortMaster 3” chapter in the *PortMaster 3 Installation Guide* for more information. Change the values and addresses shown to match your actual requirements.

In this example, the RADIUS and RADIUS accounting servers are at 192.168.1.3, the default routing gateway is 192.168.1.1, and the PM-3 will assign dynamic IP addresses to dial-in users from the range 192.168.1.4 through 192.168.1.49 (if using two 23 channel PRI's) or 192.168.1.63 (if using two 30 channel PRI's).

```
set password Hard2Guess
set ether0 address 192.168.1.2
set gateway 192.168.1.1
set isdn-switch att-5ess
save all
reboot

set assigned 192.168.1.4
set loghost 192.168.1.3
set authenticate 192.168.1.3
set accounting 192.168.1.3
set secret UpTo15Character
save all
```

Copyright and Trademarks

© Copyright 1997 Livingston Enterprises, Inc. All rights reserved.

The names Livingston, PortMaster, ComOS, RADIUS, ChoiceNet, PMconsole, IRX, True Digital, RAMP, and Total Access. Sure and Simple. are trademarks of Livingston Enterprises, Inc. All other marks are the property of their respective owners.

Notices

Livingston Enterprises, Inc. makes no representations or warranties with respect to the contents or use of this manual, and specifically disclaims any express or implied warranties of merchantability or fitness for any particular purpose. Further, Livingston Enterprises, Inc. reserves the right to revise this publication and to make changes to its content, any time, without obligation to notify any person or entity of such revisions or changes.

Contacting Livingston Technical Support

Every Livingston product comes with a one year hardware warranty.

To obtain technical support, contact Livingston Enterprises Monday through Friday between the hours of 6 a.m. and 5 p.m. (GMT -8). Please record your Livingston ComOS version number and report it to the technical support staff.

By voice, dial (800) 458-9966 within the USA (including Hawaii), Canada, and the Caribbean, or +1 (510) 426-0770 from elsewhere. By FAX, dial +1 (510) 426-8951. By electronic mail, send mail to "support@livingston.com." Using the World Wide Web, see "<http://www.livingston.com/>."

You can schedule one-hour installation appointments in advance by calling the technical support telephone number listed above. New releases and upgrades of Livingston software are available via anonymous FTP from "[ftp.livingston.com](ftp://ftp.livingston.com)."